

## **Remote Controller User Guide (2<sup>nd</sup> Generation)**



Version: 1.0

Date: March 5<sup>th</sup>, 2014



## **General Notes:**

All materials contained on this documentation is protected by the copyright law and may not be reproduced, transmitted, published or broadcasted without the prior obtaining authorization of Wonde Proud Technology. The documentation is provided for testing, evaluation, integration and product information purpose and it may contain deficiencies or inadequacies information of products. This product is not intended for use in life support appliance, devices or systems where a malfunction of the product can reasonably be expected to result personal injury. Wonde Proud or its supplier will not be liable for any consequential, direct, indirect, incidental, punitive or other damages including without limitation, damages for loss of business profits, business interruption, loss of business information or other pecuniary loss that arising out the use of or inability to use the documentation or product, even if Wonde Proud has been advised of the possibility of such damages. The customers using or reselling the product in such application do so at their own risk and agree to full indemnify Wonde Proud for any damages resulting from illegal use or resale. Subject to change without notice at any time.

## **Copyright**

Reproduction, dissemination, edition of this document, or utilization of the content and communication format as well as giving to other without authorization are prohibited. Offenders will be held liable for payment of damages.

**Copyright ©Wonde Proud Technology 2007. All right are reserved.**



# **WONDE PROUD TECHNOLOGY**

## **Table of Content**

1. Introduction of Hardware: .....	1
2. Change the Battery: .....	2
3. Switch Active/Passive Mode: .....	3
4. About Wonde Proud Technology: .....	4

## 1. Introduction of Hardware:



### Note:

- ✚ All buttons could be customized for different functions and purposes.
- ✚ Adopt 2.4GHz Wireless technology for data transmission.
- ✚ Battery Type: Lithium Battery CR2032.
- ✚ LED display would quick blink as soon as button is pressed which indicates that data packet has been sent out through radio frequency successfully.

## 2. Change the Battery:

Please follow steps below to change internal battery:


- a. Find the notch near the key ring and snap cover open using a small flathead screwdriver.
- b. Remove PCB from holder gently and flip it over.
- c. Replace with new batteries.
- d. Flip PCB back and place it into holder gently.
- e. Clip cover onto holder tightly without any gap and make sure to hear a “Click”.



### 3. Switch Active/Passive Mode:

Please follow steps below to switch into active/passive mode:

- Find the notch near the key ring and snap cover open using a small flathead screwdriver.
- Remove PCB from holder gently and flip it over.
- Find the switch near arc and follow the arrow to switch into passive/active mode.
- Flip PCB back and place it into holder gently.
- Clip cover onto holder tightly without any gap and make sure to hear a “Click”.



Note:

- Remote controller would be switched into passive mode before shipment.

#### **4. About Wonde Proud Technology:**

WondeX VT10 device is manufactured by Wonde Proud Technology. Wonde Proud Technology provides advanced solution for GPS related solutions including the various GPS components, Automatic Vehicle Location (AVL) device (data logger & real time tracking devices). Please contact us at the phone and fax number list below or visit our website for further product information.



***Wonde Proud Technology***

**Web site:** <http://www.wondeproud.com>

**Tel:** +886-2-26968498

**Fax:** +886-2-26968499

**Address:** 4F., No.100,Sec.1,Shin Tai Wu Rd, Sijhih city, Taipei county 22102, Taiwan. R.O.C